IMPORTANT!

The contents of this pattern are copyright protected and belong exclusively to VikiSews. You may use VikiSews patterns for personal use. It is prohibited to share VikiSews patterns and instructions with third parties, as well as to publish patterns and instructions online for public access. You may use VikiSews patterns for commercial use, to sew custom-made garments and/or create garment collections, on the condition that the patterns are solely used in a manufacturing setting and are not further shared with individuals.

MARISA

#vikisews

PATTERN DESCRIPTION

Marisa is a semi-fitted double-breasted blazer. The bust darts are vertical and merge with the waist darts, ending with the pocket opening. Marisa features double welt pockets with flaps located at the waist level, front and back side panels, back shoulder darts and center back seam with a vent, and long two piece sleeves. The stand collar blends with the front edge, forming a sharp V neckline and the front flaps below the waist are slanted. The blazer fastens with buttons and buttonholes and is fully lined. Marisa is mid hip length.

TOTAL WEARING EASE

Bust ease,	Waistline ease,	Hipline ease,	Upper arm
cm	cm	cm	ease, cm
10,2-12	14	10,6-11,1	8

GARMENT LENGTH, SLEEVE LENGTH

Height, cm	Garment length, cm	Sleeve length, cm
1 (154-160)	68,2	59,4-61,2
2 (162-168)	71,1	61,3-63,1
3 (170-176)	74, ^I	63,2-65
4 (178-184)	77, ¹	65,1-66,9

SUGGESTED FABRIC

To sew this blazer, choose woven fabrics with the following properties:

- Medium weight, flexible, breathable, soft, non-stretch or with very little stretch, opaque;
- The fiber content can include natural fibers (wool, silk, cotton, linen), artificial (viscose), blends (wool + silk, wool + polyester, cotton + viscose, etc), and synthetic (polyester, polyester + elastane);
 - The following fabrics are recommended: wool suiting, gabardine, linen suiting, velvet suiting, denim.

Attention! We do not recommend stretchy knit materials and lightweight sheer fabrics (chiffon, organza, stretch lace).

For the lining, we recommend artificial fibers (viscose), blends (viscose + elastane, viscose + polyester), or synthetic fibers (polyester, polyester + elastane).

The blazer on the photo is made with wool suiting. This material is medium weight, flexible, soft, non-stretch. The fiber content is a blend of wool and viscose. The lining is 100% viscose.

FABRIC AND NOTIONS REQUIREMENTS

1. Main fabric, 140cm wide, in meters:

Height, cm	Size 34-40	Size 42-46	Size 48-52
1 (154-160)	1,57	1,84	1,93
2 (162-168)	1,61	1,91	2,02
3 (170-176)	1,67	1,98	2,09
4 (178-184)	1,73	2,06	2,18

2. Lining fabric, 140cm wide:

Height, cm	Size 34	Size 36-48	Size 50-52
1 (154-160)	1,37	1,4	1,5
2 (162-168)	1,42	1,45	1,55
3 (170-176)	1,47	1,5	1,6
4 (178-184)	1,52	1,55	1,66

3. Fusible knit or woven interfacing, 140cm wide:

	Yardage, m		
Height, cm	Size 34-40	Size 42-52	
1 (154-160)	1,34	1,55	
2 (162-168)	1,4	1,59	
3 (170-176)	1,46	1,63	
4 (178-184)	1,52	1,67	

IMPORTANT!


When purchasing fabric, please account for shrinkage and buy 5% more than required.

- 4. Fusible seam tape interfacing 1m.
- 5. Shoulder pads one pair.
- 6. Two buttons 2.5cm in diameter.
- 7. One backing button 2-2.2cm in diameter.
- 8. Matching thread, 1 spool.

TOOLS AND EQUIPMENT

- Sewing machine for construction;
- Buttonhole foot for your sewing machine;
- Stitch-in-the-ditch foot for your sewing machine (optional).





Fully interface the following pieces:

- Back 2 pieces
- Front 2 pieces
- Front side panel 2 pieces
- Back side panel 2 pieces
- Collar 2 pieces
- Front facing 2 pieces
- Top welt 2 pieces
- Bottom welt 2 pieces
- Pocket facing 2 pieces
- Top flap 2 pieces
- Bottom flap 2 pieces
- Back neck facing 1 piece cut on fold



To interface, put the gluey side of the interfacing (the side that feels rough to the touch) on top of the wrong side of the fabric piece (or a section thereof) and press with the iron. Do not iron the piece, but instead press it section by section, holding it down with the iron a few seconds until that section is adhered and then pressing down the next section. You may use a cotton pressing cloth to protect your iron sole. Once the interfacing process complete, leave the piece on a hard flat surface for 15 minutes for it to cool down.



Partially interface the following:

- Top sleeve 2 pieces
- Bottom sleeve 2 pieces